

Using cirQWizard and cirQoid
12/12/18

Use Device Manager to find Serial Port

Go to Home/Settings/Application in cirQWizard and set the Serial port

X & Y Directions

Y is away from front of machine

X is side to side

Use Manual control/Tool change to help changing bits

Z offset -18.7